


Maytag MDG12PDBBL 03 - CABINET-FRONT



Maytag Residential Maytag MDG12PDBBL Dryer Parts Parts Diagram 03 - CABINET-FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	CONSOLE (WHT)
002	212276	W10116760		Screw
003	33001740			Cover, Top
"	NLA		Not Available	(ALM)
004	33001486	98008544		Screw
"	NLA		Not Available	PANEL, FRONT (WHT)---NA
005	33001241			Handle, Door
"	33001254	37001047		Handle, Door
006	214354			Screw, Top Cover To Cabnt.
007	33001230			Hinge, Door
008	22001496			Front Panel Fastener And Screw
009	215075			Fastener, Control Panel To Console
010	Y313561			Screw---NA
"	Y310632	1163839		Screw
011	V302361		Not Available	BASE ASSY. (UPPER &

011	1303301	Not Available	LOWER)
012	Y314137		Foot, Rubber
013	Y305086		Adjustable Leg And Nut
014	Y052740	62739	Nut, Lock
015	213007		Xfor Cabinet See Cabinet, Back
016	NLA	Not Available	CABINET (WHT)
017	210186	3370225	Screw
018	33001614	Not Available	PLUG, FRONT PANEL (WHT)
"	33001615	Not Available	PLUG, FRONT PANEL (ALM)

