


Maytag MDG12PRBAW 04 - CABINET-REAR



Maytag Residential Maytag MDG12PRBAW Dryer Parts Parts Diagram 04 - CABINET-REAR
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|---------------------------|---------------|---|
| 001 | Y312905 | | Not Available | COVER, TERMINAL |
| 002 | Y313561 | | | Screw----NA |
| 003 | 311484 | 112432 | | Nut |
| 004 | Y312184 | | | Strap, Grounding |
| 005 | 33001244 | | | Block, Terminal |
| 006 | Y312904 | | | Bracket, Terminal Block |
| 007 | Y312209 | W10001200 | | Screw |
| 008 | Y311270 | | | Washer, Terminal Block |
| 009 | Y310632 | 1163839 | | Screw |
| 010 | NLA | | Not Available | SCREW, GROUND STRAP |
| 011 | 22001178 | 22003062 | | Cord, Power |
| " | 305168 | 33002916 | | Power Cord, Canadian 240V |
| " | 33001425 | | | Locknut, Eared For Canadian |
| 012 | 211881 | | | Grommet, Cord Part Not Used- Gas Models Only |
| 013 | NLA | | Not Available | SCREW & WASHER ASSY. |
| 014 | 216423 | 3370225 | | Screw |

| | | | | |
|-----|-------------------------|-------------------------|---------------|--------------------------------|
| 015 | Y312951 | | Not Available | ACCESS COVER, BACK |
| 016 | Y305086 | | | Adjustable Leg And Nut |
| 017 | Y314137 | | | Foot, Rubber |
| 018 | Y052740 | 62739 | | Nut, Lock |
| 019 | Y303361 | | Not Available | BASE ASSY. (UPPER & LOWER) |
| 020 | 213007 | | | Xfor Cabinet See Cabinet, Back |
| 021 | NLA | | Not Available | CABINET (WHT) |
| 022 | Y313561 | | | Screw---NA |
| " | Y310632 | 1163839 | | Screw |
| 023 | Y310376 | | | Clip, Door Switch Harness |

the laundry company[®]

the laundry company[®]

the laundry company[®]