


# Maytag MDG12PSBAW 05 - CABINET-REAR



Maytag Residential Maytag MDG12PSBAW Dryer Parts Parts Diagram 05 - CABINET-REAR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312905		Not Available	COVER, TERMINAL
002	<a href="#">Y313561</a>			Screw----NA
003	311484	<a href="#">112432</a>		Nut
004	<a href="#">Y312184</a>			Strap, Grounding
005	<a href="#">33001244</a>			Block, Terminal
006	<a href="#">Y312904</a>			Bracket, Terminal Block
007	Y312209	<a href="#">W10001200</a>		Screw
008	<a href="#">Y311270</a>			Washer, Terminal Block
009	Y310632	<a href="#">1163839</a>		Screw
010	NLA		Not Available	SCREW, GROUND STRAP
011	22001178	<a href="#">22003062</a>		Cord, Power
"	305168	<a href="#">33002916</a>		Power Cord, Canadian 240V
"	<a href="#">33001425</a>			Locknut, Eared For Canadian
012	<a href="#">211881</a>			Grommet, Cord Part Not Used- Gas Models Only
013	NLA		Not Available	SCREW & WASHER ASSY.
014	216423	<a href="#">3370225</a>		Screw

015	Y312951		Not Available	ACCESS COVER, BACK
016	<a href="#">Y305086</a>			Adjustable Leg And Nut
017	<a href="#">Y314137</a>			Foot, Rubber
018	Y052740	<a href="#">62739</a>		Nut, Lock
019	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
020	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
021	NLA		Not Available	CABINET (WHT)
022	<a href="#">Y313561</a>			Screw---NA
"	Y310632	<a href="#">1163839</a>		Screw
023	<a href="#">Y310376</a>			Clip, Door Switch Harness

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>