


# Maytag MDG13CSABW 02 - CONTROL CENTER



\* CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Residential Maytag MDG13CSABW Dryer Parts](#) Parts Diagram 02 - CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y307081</a>			Coin Meter Weld Assembly
"	NLA		Not Available	(ALM)
002	205423	<a href="#">208883</a>		Coin Box K
"	205423L	<a href="#">208883</a>		Coin Box K
003	212328	<a href="#">W10139762</a>		Hex Nut, 3/4-27
004	<a href="#">315277</a>			Screw
005	Y052634	<a href="#">701719</a>		Nut, Hex
006	910708	<a href="#">488234</a>		Screw 8-32 X 1/4
007	<a href="#">305870</a>			Timer Motor
"	306527	<a href="#">305812</a>		Timer
008	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
009	<a href="#">215559</a>			Bolt, Coin Slide Locking
010	<a href="#">910387</a>			Lockwasher, Vault Assembly
011	<a href="#">Y052721</a>			Nut, Terminal Block Plate
012	NLA		Not Available	SPRING, HELICAL
013	<a href="#">314331</a>			Spring, Torsion Return

014	<a href="#">314332</a>		Spring, Actuator
015	<a href="#">306104</a>		Actuator Switch Kit
016	212707	<a href="#">3196385</a>	Screw
017	<a href="#">305800</a>		Wire Harness For Timer
018	<a href="#">305796</a>		Timer
"	<a href="#">305812</a>		Timer
"	<a href="#">305813</a>		Part Not Available Part Not Used
019	Y313671	<a href="#">33001303</a>	Grommet, Plate Hole
020	<a href="#">Y308109</a>		Slide And Adj. Return Bracket
021	<a href="#">305797</a>		Torsion Timer Assembly Complete
"	<a href="#">305831</a>		Torsion Timer Assembly
"	NLA	Not Available	TIMER TORSION ASSEMBLY
022	314337	<a href="#">33002968</a>	Slider
023	305798	Not Available	BYPASS SWITCH FOR MOTOR
024	<a href="#">Y305799</a>		Bypass Switch For Heater
025	<a href="#">211790</a>		Lock Ring For Timer Shaft
026	<a href="#">Y312270</a>		Clip, Spring Retainer
027	314330	Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
028	<a href="#">314335</a>		Peg, Tine Adjustment
"	314547	<a href="#">Y308109</a>	Slide And Adj. Return Bracket
029	<a href="#">314339</a>		Switch And Slider Bracket
030	<a href="#">314546</a>		Wheel, Index
031	<a href="#">211065</a>		Spring, Index Wheel
032	314548	<a href="#">33002967</a>	Actuator, Switch
033	<a href="#">314334</a>		Bracket For Coin Slide
034	<a href="#">314333</a>		Timer Mounting Bracket
035	NLA	Not Available	STOP, COIN METER
036	<a href="#">Y014872</a>		Screw, Coin Meter Stop -

