


Maytag MDG13CSEGW 05 - REAR



Maytag [Residential Maytag MDG13CSEGW Dryer Parts](#) Parts Diagram 05 - REAR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	308966		Not Available	CORD, POWER (EXPORT)
"	33001284		Not Available	CORD, POWER
"	33001285		Not Available	CORD, POWER
002	211881			Grommet, Cord Part Not Used-Gas Models Only
"	NLA		Not Available	GROMMET, POWER CORD
003	Y312905		Not Available	COVER, TERMINAL
004	Y313561			Screw---NA
005	NLA		Not Available	SCREW, SHROUD
006	Y313559			Screw
007	213007			Xfor Cabinet See Cabinet, Back
008	NLA		Not Available	SCREW, SPACER ASSEMBLY
"	Y310632	1163839		Screw
009	216423	3370225		Screw
010	Y313561			Screw---NA

"	Y310632	1163839		Screw
011	NLA		Not Available	SHROUD, CONTROL (WHT)
012	NLA		Not Available	PLATE, TOP COVER
013	NLA		Not Available	COVER, TOP (WHT)
014	NLA		Not Available	SCREW & WASHER ASSEMBLY
015	NLA		Not Available	CABINET (UPR-ALM)
"	Y310632	1163839		Screw
016	33001302			(WHT)
"	NLA		Not Available	SPACER ASSEMBLY (ALM)
017	310933	33002194		Nut, Speed
018	Y302699	22003428		Leg, Adjustable
019	210684			Foot, Adjustable Leg
020	210385			Lock Nut For Adjustable Leg
021	Y312951		Not Available	ACCESS COVER, BACK
022	NLA		Not Available	STRIP, FILLER
023	311155			Ground Wire And Clamp
024	301548			Clamp, Ground Wire

