


Maytag MDG13PDBBW 03 - DOOR



Maytag [Residential Maytag MDG13PDBBW Dryer Parts](#) Parts Diagram 03 - DOOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y314062			Screw, Door Hinge And Panel
002	33001230			Hinge, Door
003	314967		Not Available	DOOR W/WINDOW OUTER HALF (WHT)
"	NLA		Not Available	(ALM)
004	314939			Handle, Door
"	314974			Handle, Door
005	33001192			Seal, Door
006	33001305			Strike, Door
007	Y304578	LA-1003		Door Catch Kit
008	212982	22001650		Fastener, Spring
009	Y310376			Clip, Door Switch Harness
010	33001420			Switch, Door
011	314937			Seal, Front Panel
012	NLA		Not Available	CLIP, HINGE SCREW
"	NLA		Not Available	SCREW, PLASTIC
013	33001447		Not Available	PANEL, FRONT (UPR-WHT)

"	33001486	98008544	Screw
"	NLA	Not Available	PANEL, FRONT (UPR-ALM)
014	NLA	Not Available	PLUG, DOOR CATCH
015	33001175		Cover, Hinge Hole
"	33001176		Cover, Hinge Hole
016	Y313910		Clip, Door Liner To Outer Panel
017	22001496		Front Panel Fastener And Screw
018	33001203	Not Available	PANEL, CLEAR INNER (W/SEAL)
019	33001614	Not Available	PLUG, FRONT PANEL (WHT)
"	33001615	Not Available	PLUG, FRONT PANEL (ALM)
020	315489		Screw, Extrusion And Front

the laundry company[®]

the laundry company[®]

the laundry company[®]