


Maytag MDG13PRBAW 01 - CONTROLS & UPPER PANEL



***Contact Your Commercial Distributor for Locks & Keys**

Maytag [Residential Maytag MDG13PRBAW Dryer Parts](#) Parts Diagram 01 - CONTROLS & UPPER PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001711	33002936		Medallion-
002	33001447		Not Available	PANEL, FRONT (UPR-WHT)
"	33001486	98008544		Screw
003	212982	22001650		Fastener, Spring
004	Y310376			Clip, Door Switch Harness
005	912012	3400409		Screw
"	Y306232			Switch, Access
006	314625	206637		Lock Kit
007	Y303981			Ground Wire For Latch
008	NLA		Not Available	COVER, COIN DROP
009	314654			Bolt, Coin Drop Cover
010	310933	33002194		Nut, Speed
011	NLA		Not Available	EXTRUSION (LWR)
012	Y313561			Screw---NA
"	314631			Bracket, Coin Mechanism
"	Y310632	1163839		Screw

013	NLA		Not Available	SUPPORT ASSEMBLY (WHT)
014	306233		Not Available	STRAP, COIN ACCEPTOR
015	33001201			Plate, Control Mounting
"	910186	99002757		Screw
016	33001156			Button, Control
017	33001209			Cover, Display
018	NLA		Not Available	EXTRUSION, CONTROL (UPR)
019	314634			Bracket, Access Switch
020	33001204			Stand-Off, Ccontrol Board
021	912077			Locknut, Reader Harness
022	33001747	33002605		Circuit Board Assembly
023	Y052659	Y052655		Hex Nut, No.8-32
024	33001200	33002449		Switch, Membrane
025	314522			Grommet, Strain Relief
"	910768	M0280301		Tie Electr
"	NLA		Not Available	WIRE HARNESS, MAIN (UPR)
026	215506			Screw, Control Panel Overlay
"	315489			Screw, Extrusion And Front
027	215506			Screw, Control Panel Overlay
028	314666		Not Available	SCREW, PANEL (UPR)
"	NLA		Not Available	CLIP, CABINET SCREW
029	212328	W10139762		Hex Nut, 3/4-27
030	22001354	W10177242		Hex-Nut 9/32 - 28
031	22001355			Nut, Lock Cam
032	33001157		Not Available	PLATE, COIN DROP COVER (PART NOT USED)
033	NLA		Not Available	HARNESS, PR OPTIC PLUG

the laundry company[®]

lws
the laundry company[®]