


# Maytag MDG14PRAXW 02 - CABINET-FRONT



Maytag [Residential Maytag MDG14PRAXW Dryer Parts](#) Parts Diagram 02 - CABINET-FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">33002627</a>			Cover, Top
"	NLA		Not Available	CABINET (WHT)
002	<a href="#">22001959</a>			Wire, Ground
003	210186	<a href="#">3370225</a>		Screw
004	NLA		Not Available	BRACKET, TERMINAL BLOCK---NA
005	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
006	<a href="#">33001244</a>			Block, Terminal
007	Y312209	<a href="#">W10001200</a>		Screw
008	<a href="#">Y311270</a>			Washer, Terminal Block
009	<a href="#">Y312184</a>			Strap, Grounding
010	NLA		Not Available	SCREW, GROUND STRAP
011	311484	<a href="#">112432</a>		Nut
012	<a href="#">311093</a>			Washer, Terminal Connection
013	<a href="#">22003639</a>			Cabinet Assembly
014	310933	<a href="#">33002194</a>		Nut, Speed

015	33001872	<a href="#">33002891</a>	Pin, Locator
016	<a href="#">22002049</a>		Clip Note: Clip, Front Panel
017	213280	<a href="#">204439</a>	Screw And Fstner Assembly
018	<a href="#">22001995</a>		Screw Note: Screw, Tumbler Front And Shroud
019	<a href="#">Y310376</a>		Clip, Door Switch Harness
020	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
"	22003409	<a href="#">213007</a>	Xfor Cabinet See Cabinet, Back
021	213280	<a href="#">204439</a>	Screw And Fstner Assembly
"	<a href="#">22002239</a>		Clip, Front Panel
022	33002073	<a href="#">Y310376</a>	Clip, Door Switch Harness
023	<a href="#">33001836</a>		Strap, Top Cover Support

*the laundry company*<sup>®</sup>

**How**  
*the laundry company*<sup>®</sup>

**How**  
*the laundry company*<sup>®</sup>