


# Maytag MDG16CSDWQ 02 - CONTROL CENTER



• CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Residential Maytag MDG16CSDWQ Dryer Parts](#) Parts Diagram 02 - CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22002478		Not Available	VAULT, COIN (WHT) (ORIGINAL COIN VAULT NLA USE)
"	<a href="#">22002885</a>			Vault, Coin
002	22001810		Not Available	STRAP, MOUNTING
003	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
004	<a href="#">910309</a>			Washer, Mounting Strap
005	<a href="#">22002072</a>			Gasket, Control Center
"	<a href="#">22002618</a>			Gasket, Control Center
006	Y052740	<a href="#">62739</a>		Nut, Lock
007	22001903	<a href="#">8576635</a>		Bolt
008	<a href="#">910387</a>			Lockwasher, Vault Assembly
009	<a href="#">Y052721</a>			Nut, Terminal Block Plate
010	<a href="#">22003677</a>			Nut, Locking Cam
011	<a href="#">33001195</a>			Wire Harness, Timer
012	<a href="#">33002115</a>			Timer

"	<a href="#">33002136</a>		Timer
013	<a href="#">22001881</a>		Grommet, Double
"	<a href="#">22001882</a>		Latch, Access Door
"	22001883	<a href="#">214354</a>	Screw, Top Cover To Cabnt.
"	<a href="#">22003679</a>		Timer Access Door Assembly
"	<a href="#">22003692</a>		Timer Access Door Assembly
014	<a href="#">33002598</a>		Actuator, Dryer Kit
015	<a href="#">33001275</a>		Torsion Timer Assembly
"	<a href="#">33001276</a>		Torsion Timer Assembly
016	314337	<a href="#">33002968</a>	Slider
017	305798	Not Available	BYPASS SWITCH FOR MOTOR
018	<a href="#">Y305799</a>		Bypass Switch For Heater
019	<a href="#">211790</a>		Lock Ring For Timer Shaft
020	<a href="#">Y312270</a>		Clip, Spring Retainer
021	314330	Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
022	<a href="#">314335</a>		Peg, Tine Adjustment
"	314547	<a href="#">Y308109</a>	Slide And Adj. Return Bracket
023	<a href="#">314339</a>		Switch And Slider Bracket
024	<a href="#">314546</a>		Wheel, Index
025	<a href="#">211065</a>		Spring, Index Wheel
026	314548	<a href="#">33002967</a>	Actuator, Switch
"	<a href="#">33002967</a>		Actuator, Switch
027	<a href="#">33001708</a>		Bracket, Coin Slide
028	33001207	<a href="#">33002702</a>	Timer Bracket
029	NLA	Not Available	SPRING, HELICAL
030	<a href="#">314331</a>		Spring, Torsion Return
031	<a href="#">314332</a>		Spring, Actuator
032	<a href="#">306104</a>		Actuator Switch Kit
033	212707	<a href="#">3196385</a>	Screw
034	<a href="#">315277</a>		Screw
035	Y052634	<a href="#">701719</a>	Nut, Hex
036	910708	<a href="#">488234</a>	Screw 8-32 X 1/4
037	211168	<a href="#">W10139210</a>	Screw, 8-18 X 5/16

