


# Maytag MDG16MNBGW 06 - MOTOR DRIVE



Maytag Residential Maytag MDG16MNBGW Dryer Parts Parts Diagram 06 - MOTOR DRIVE  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">33001789</a>			Housing, Blower
002	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
"	<a href="#">33001800</a>			Duct Assembly, Exhaust
003	410233	<a href="#">9703438</a>		Ring-Retrn
004	<a href="#">33001790</a>			Wheel, Blower
"	<a href="#">33002797</a>			Wheel, Blower
005	<a href="#">312967</a>			Clamp, Blower Housing
006	33001855	<a href="#">33002917</a>		Screw, No.10-16
007	<a href="#">Y313561</a>			Screw----NA
008	<a href="#">303392</a>			Thermostat, Cycling
"	<a href="#">306966</a>			Thermostat, Multi-Temp Part Not Used Mdg26ct-MN Only
009	22001996	<a href="#">3370225</a>		Screw
010	<a href="#">33001762</a>			Fuse, Thermal
011	NLA		Not Available	SCREW, THERMAL CUT-OFF
012	<a href="#">Y314137</a>			Foot, Rubber

013	33001796	<a href="#">33002711</a>	Cover, Blower Housing
"	<a href="#">33002711</a>		Cover, Blower Housing
014	314818	<a href="#">1163839</a>	Screw
015	33001853	<a href="#">33002478</a>	Motor
"	33001945	<a href="#">W10197708</a>	Motor-Drve
"	33002237	<a href="#">33002478</a>	Motor
"	33002462	<a href="#">33002478</a>	Motor
"	33002463	<a href="#">W10197708</a>	Motor-Drve
"	<a href="#">33002478</a>		Motor
"	33002479	<a href="#">W10197708</a>	Motor-Drve
"	<a href="#">33002795</a>		Motor, Drive 60Hz
"	33002796	<a href="#">W10197708</a>	Motor-Drve
016	33002221	<a href="#">Y015825</a>	Clip, Motor To Motor Support
"	<a href="#">Y015825</a>		Clip, Motor To Motor Support
017	910343	<a href="#">488234</a>	Screw 8-32 X 1/4
018	33001854	<a href="#">33002478</a>	Motor
"	NLA	Not Available	SWITCH, MOTOR
019	<a href="#">901220</a>		Ground Wire
020	<a href="#">Y310376</a>		Clip, Door Switch Harness
021	33001754	<a href="#">33002459</a>	Assembly, Spring And Plug
"	<a href="#">33002157</a>		Grommet
"	33002460	<a href="#">33002459</a>	Assembly, Spring And Plug
"	<a href="#">33002461</a>		Plug For Spring
022	33001782	<a href="#">6-3705180</a>	Idler Arm
"	33001840	<a href="#">6-3705180</a>	Idler Arm
023	<a href="#">Y312527</a>		Washer, Idler Shaft
024	33001783	<a href="#">6-3700340</a>	BearIng- I
025	312958	<a href="#">354987</a>	Ring, Retaining
026	<a href="#">315772</a>		Sleeve, Idler Arm
027	<a href="#">Y014874</a>		Screw, Idler Arm And Sleeve
028	<a href="#">Y313561</a>		Screw---NA
"	33001752	<a href="#">33002817</a>	Motor Support, Offset
"	33002466	<a href="#">33002817</a>	Motor Support, Offset
029	<a href="#">Y313561</a>		Screw---NA
030	<a href="#">33002622</a>		Base,
"	NLA	Not Available	BASE
031	22001078	<a href="#">3177991</a>	Screw
032	315471	<a href="#">22003298</a>	Retainer, Wire
033	<a href="#">410490</a>		Spring, Retainer Wire Harness
034	<a href="#">Y305086</a>		Adjustable Leg And Nut
035	Y052740	<a href="#">62739</a>	Nut, Lock
036	211294	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">33001948</a>		Transformer Lower
"	<a href="#">Y313559</a>		Screw