


Maytag MDG170P1HW 04 - FRONT PANEL/MAIN DOOR ASSEMBLY



Maytag [Residential Maytag MDG170P1HW Dryer Parts](#) Parts Diagram 04 - FRONT PANEL/MAIN DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A820929	820929		170-Front
002	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.)
003	A150412		Not Available	SCREW, CRIMPTITE (PH.RD.HD.) (No.10-16 X 3/4" PH. RD. HD.)
004	A112360		Not Available	LOGO (LOGO TAPE KIT NOT INCLUDED)
"	A870011	W10147884		Logo Doubl
005	A170340	170340		3 1 2 SS
006	A154200			5 32 RIVE
007	A102308		Not Available	GASKET, DOOR (94" LNGT. ONLY)
008	A102210	102210		20 7 16 D
"	A170730	170730		10.3 Oz CI

009	A150401	W10146762		10-24 X 1
010	A306801	306801		Wire Harness, Main
011	A102102	102102		Door Magnet
012	A150309	W10146761		10-16 X 1
013	A180150	180150		35 Door H
014	A800122	W10146962		100 Main
"	A800125		Not Available	DOOR ASSY. W/GLSS & GSKT ONLY (INCLUDES 7, 8 AND 14)
"	A800128	W10146964		100 120 S
"	A800265		Not Available	DOOR ASSY. W/GRAY HANDLE (INCLUDES 7 - 14, SPECIFY
015	A150430	150430		10 X 1 2
016	A180155		Not Available	BLOCK, DOOR HINGE (ONLY) (35" CROSS GRAY)

