


Maytag MDG21PDDGW 03 - CABINET-FRONT



Maytag [Residential Maytag MDG21PDDGW Dryer Parts](#) Parts Diagram 03 - CABINET-FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33002629			Cover, Top
002	22001959			Wire, Ground
003	210186	3370225		Screw
004	NLA		Not Available	BRACKET, TERMINAL BLOCK---NA
005	22001995			Screw Note: Screw, Tumbler Front And Shroud
006	33001244			Block, Terminal
"	33002106			Shield, Terminal Block
007	Y312209	W10001200		Screw
008	Y311270			Washer, Terminal Block
009	Y312184			Strap, Grounding
010	Y312209	W10001200		Screw
011	311484	112432		Nut
012	311093			Washer, Terminal Connection
013	22003639			Cabinet Assembly
014	310933	33002194		Nut, Speed

015	22002049		Clip Note: Clip, Front Panel
016	213280	204439	Screw And Fstner Assembly
017	22001995		Screw Note: Screw, Tumbler Front And Shroud
018	Y310376		Clip, Door Switch Harness
019	22003409	213007	Xfor Cabinet See Cabinet, Back
020	22002239		Clip, Front Panel
021	33001836		Strap, Top Cover Support
022	206824	W10133335	Relay, Motor
023	306199		Relay, Heater
"	33002969	W10133335	Relay, Motor
"	Y251119	3177991	Screw
024	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	314627		Bracket, Relays

