


Maytag MDG2300BWW 01 - CABINET-FRONT



Maytag Residential Maytag MDG2300BWW Dryer Parts Parts Diagram 01 - CABINET-FRONT
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|------------------------|--------|---|
| 1 | 33002631 | | | Cover, Top |
| " | 33001896 | | | Cover, Top |
| 2 | 33002624 | | | Cabinet, Assembly |
| " | 33001897 | | | Cabinet |
| " | 22003643 | | | CABINET ASSY. (WHT AS PK) |
| 3 | 22002049 | | | Clip Note: Clip, Front Panel |
| 4 | 213280 | 204439 | | Screw And Fstner Assembly |
| 5 | 22001995 | | | Screw Note: Screw, Tumbler Front And Shroud |
| 6 | Y310376 | | | Clip, Door Switch Harness |
| 7 | 22003409 | 213007 | | Xfor Cabinet See Cabinet, Back |
| " | 213007 | | | Xfor Cabinet See Cabinet, Back |
| 8 | 22003298 | | | Retainer, Wire |