


Maytag MDG27CSABW 02 - REAR



8

Maytag Residential Maytag MDG27CSABW Dryer Parts Parts Diagram 02 - REAR

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
002	211881			Grommet, Cord Part Not Used-Gas Models Only
003	Y312905		Not Available	COVER, TERMINAL
004	Y313561			Screw----NA
005	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
006	Y311423	489483		Screw 10-32 X 1/2
"	Y312184			Strap, Grounding
007	400008			Block, Terminal
"	Y312209	W10001200		Screw
008	Y312904			Bracket, Terminal Block
009	Y311270			Washer, Terminal Block
010	311484	112432		Nut
011	NLA		Not Available	SCREW
012	NLA		Not Available	TOP COVER PLATE

"	Y313559		Screw
013	307104		Top Cover Assembly
"	NLA	Not Available	(ALMOND)
014	NLA	Not Available	SCREW & WASHER ASSY.
015	213007		Xfor Cabinet See Cabinet, Back
"	307125	Not Available	CABINET, LOWER (WHITE)
"	NLA	Not Available	(ALMOND)
"	Y310632	1163839	Screw
016	911050	4312464	Screw
"	NLA	Not Available	SPACER ASSY, WHITE
"	Y310632	1163839	Screw
017	310933	33002194	Nut, Speed
018	Y302699	22003428	Leg, Adjustable
019	210684		Foot, Adjustable Leg
020	210385		Lock Nut For Adjustable Leg
021	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y312951	Not Available	ACCESS COVER, BACK
"	Y313559		Screw
022	NLA	Not Available	FILLER STRIP
"	Y310632	1163839	Screw
023	311155		Ground Wire And Clamp
024	301548		Clamp, Ground Wire
"	313122		Screw - Baffle To Tumbler

