


# Maytag MDG27CTABL 05 - CONTROL CENTER COMPONENTS



Maytag Residential Maytag MDG27CTABL Dryer Parts Parts Diagram 05 - CONTROL CENTER COMPONENTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	204882		Not Available	SWITCH FOR TICKET CONTROL
"	NLA		Not Available	SCREW
002	<a href="#">204881</a>			Cam Plate Assembly
"	NLA		Not Available	SCREW
003	<a href="#">214218</a>			Lever, Switch
004	<a href="#">212452</a>			Board, Circuit
"	NLA		Not Available	SCREW
005	<a href="#">214275</a>			Roller For Cam
006	<a href="#">214220</a>			Adjustment Thumb Wheel
007	NLA		Not Available	SPRING WASHER
008	202479	<a href="#">A3167501</a>		Lamp Oven, Int.
009	NLA		Not Available	LAMP SOCKET W/BACKET
010	212519	<a href="#">488234</a>		Screw 8-32 X 1/4
"	NLA		Not Available	FRONT PLATE
011	212533			SHIELD FOR HEAT LAMP
"	NLA		Not Available	SCREW

012	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
013	NLA		Not Available	SCREW
014	<a href="#">203140</a>			Contact Ball Kit
015	NLA		Not Available	OVERLAY
016	Y311550		Not Available	SPADE (MINIATURE)
017	NLA		Not Available	JUMPER WIRE (BLACK)
018	NLA		Not Available	SPADE CONNECTOR
019	211737	<a href="#">248562</a>		Terminal
020	NLA		Not Available	HARNESS, TICKET CONTROL
021	<a href="#">213074</a>			Pin Receptacle For Plug
"	NLA		Not Available	PIN, PLUG
022	202713	<a href="#">22001555</a>		Fuse
023	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
"	311613	<a href="#">Y311711</a>		Screw, Fuse Block
024	211294	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	NLA		Not Available	BRACKET
025	NLA		Not Available	SHIELD
026	202477	<a href="#">22003292</a>		Control As
027	NLA		Not Available	FUSE BLOCK W/FUSE
028	NLA		Not Available	TICKET RECEIVER ASSY.
029	<a href="#">202509</a>			Ticket Control Assembly

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>