


Maytag MDG27MNAGW 02 - REAR



Maytag Residential Maytag MDG27MNAGW Dryer Parts Parts Diagram 02 - REAR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	POWERCORD
002	211881			Grommet, Cord Part Not Used-Gas Models Only
003	Y313561			Screw----NA
"	Y312905		Not Available	COVER, TERMINAL
004	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
005	Y311423	489483		Screw 10-32 X 1/2
"	Y312184			Strap, Grounding
006	400008			Block, Terminal
"	Y312209	W10001200		Screw
007	Y313561			Screw----NA
"	Y312904			Bracket, Terminal Block
008	Y311270			Washer, Terminal Block
009	311484	112432		Nut
010	307104			Top Cover Assembly

011	NLA	Not Available	TOP COVER PLATE
"	Y313559		Screw
012	NLA	Not Available	SCREW & WASHER ASSY.
013	213007		Xfor Cabinet See Cabinet, Back
"	NLA	Not Available	CABINET, UPPER (WHITE)
"	Y310632	1163839	Screw
014	310933	33002194	Nut, Speed
015	NLA	Not Available	SUPPORT ASSY. (WHITE)
"	Y310632	1163839	Screw
016	213007		Xfor Cabinet See Cabinet, Back
"	Y313561		Screw---NA
"	NLA	Not Available	CABINET, LOWER (WHITE)
"	Y310632	1163839	Screw
017	210385		Lock Nut For Adjustable Leg
018	Y302699	22003428	Leg, Adjustable
019	210684		Foot, Adjustable Leg
020	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313561		Screw---NA
"	Y312951	Not Available	ACCESS COVER, BACK
021	301548		Clamp, Ground Wire
"	313122		Screw - Baffle To Tumbler
022	311155		Ground Wire And Clamp

the laundry company[®]

the laundry company[®]