


# Maytag MDG3000AXA 01 - CABINET-FRONT



Maytag Residential Maytag MDG3000AXA Dryer Parts Parts Diagram 01 - CABINET-FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">33001866</a>			Cover, Top ---NA
2	33001859		Not Available	WIRE, GROUND
3	210186	<a href="#">3370225</a>		Screw
4	33001826		Not Available	BRACKET, TERMINAL BLOCK---NA
5	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
6	<a href="#">33001244</a>			Block, Terminal
7	Y312209	<a href="#">W10001200</a>		Screw
8	<a href="#">Y311270</a>			Washer, Terminal Block
9	<a href="#">Y312184</a>			Strap, Grounding
10	<a href="#">33001245</a>			Screw---NA
11	311484	<a href="#">112432</a>		Nut
12	<a href="#">311093</a>			Washer, Terminal Connection
13	33001844	<a href="#">22003640</a>		Cabinet Assembly
14	33001872	<a href="#">33002891</a>		Pin, Locator
15	<a href="#">22002049</a>			Clip Note: Clip, Front Panel

16	213280	<a href="#">204439</a>	Screw And Fstner Assembly
17	<a href="#">22001995</a>		Screw Note: Screw, Tumbler Front And Shroud
18	<a href="#">Y310376</a>		Clip, Door Switch Harness
19	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
20	<a href="#">Y310376</a>		Clip, Door Switch Harness

