


# Maytag MDG3000AXA 05 - DOOR



Maytag [Residential Maytag MDG3000AXA Dryer Parts](#) Parts Diagram 05 - DOOR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">33001767</a>			Seal, Shroud
2	22002033	<a href="#">33002597</a>		Hook, Security
3	33002116		Not Available	LABEL, SAFTEY
"	33001779	<a href="#">33002379</a>		Shroud
4	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
5	<a href="#">33001768</a>			Screw, Shroud Note: Screw, Shroud And Outlet Duct
6	33001508	<a href="#">W10169313</a>		Switch-Dor
7	<a href="#">33001760</a>			Bracket, Hinge
8	33001174	<a href="#">LA-1003</a>		Door Catch Kit
9	33001791	<a href="#">306436</a>		Door Latch Kit-W
"	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
10	<a href="#">33002094</a>			Seal, Door
11	<a href="#">22002038</a>			Clip, Door
12	<a href="#">33001793</a>			Bracket, Strike
13	<a href="#">33001761</a>			Strike, Door

14	<a href="#">22002039</a>		Clip, Door
15	<a href="#">33001763</a>		Plug, Inner Door
16	<a href="#">33001751</a>		Inner Door/ W Seal
17	<a href="#">22001817</a>		Sheet, Sound Damper
"	<a href="#">22002261</a>		Panel, Door
"	33001893	Not Available	LABEL, OPEN DOOR (DRYER)
18	<a href="#">33001759</a>		Hinge, Door
19	22002062	<a href="#">98006631</a>	Screw
20	22002064	<a href="#">489355</a>	Screw, 8 X 1/2
21	<a href="#">33001765</a>		Cover, Hinge Hole
22	<a href="#">33001787</a>		Screw, Hinge Note: Screw, Hinge Hole Cover
23	<a href="#">22002012</a>		Screw, Hinge Note: Screw, Hinge Bracket
24	33001221	<a href="#">22001817</a>	Sheet, Sound Damper
"	22002242	Not Available	PANEL, FRONT (ALM)
"	<a href="#">33001867</a>		Pad, Front

