


Maytag MDG3000AXW 01 - CABINET-FRONT



Maytag Residential Maytag MDG3000AXW Dryer Parts Parts Diagram 01 - CABINET-FRONT
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|---------------------------|---------------|---------------------------------------------|
| 1 | 33001865 | | | Cover, Top |
| 2 | 33001859 | | Not Available | WIRE, GROUND |
| 3 | 210186 | 3370225 | | Screw |
| 4 | 33001826 | | Not Available | BRACKET, TERMINAL BLOCK---NA |
| 5 | 22001995 | | | Screw Note: Screw, Tumbler Front And Shroud |
| 6 | 33001244 | | | Block, Terminal |
| 7 | Y312209 | W10001200 | | Screw |
| 8 | Y311270 | | | Washer, Terminal Block |
| 9 | Y312184 | | | Strap, Grounding |
| 10 | 33001245 | | | Screw---NA |
| 11 | 311484 | 112432 | | Nut |
| 12 | 311093 | | | Washer, Terminal Connection |
| 13 | 33001843 | 22003639 | | Cabinet Assembly |
| 14 | 33001872 | 33002891 | | Pin, Locator |
| 15 | 22002049 | | | Clip Note: Clip, Front Panel |

| | | | |
|----|--------------------------|------------------------|---------------------------------------------|
| 16 | 213280 | 204439 | Screw And Fstner Assembly |
| 17 | 22001995 | | Screw Note: Screw, Tumbler Front And Shroud |
| 18 | Y310376 | | Clip, Door Switch Harness |
| 19 | 213007 | | Xfor Cabinet See Cabinet, Back |
| 20 | Y310376 | | Clip, Door Switch Harness |

