


Maytag MDG30MC3A 03 - CONTROL BOX ASSEMBLY



Maytag [Residential Maytag MDG30MC3A Dryer Parts](#) Parts Diagram 03 - CONTROL BOX ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A122603	122603		9 Pin Sock
002	A122701	122701		MNL Socket
"	A122801	W10146716		Mate-N-Loc
003	A315010	315010		Door Outer Half White
004	A150300	5307527001		Switch
005	A150300	5307527001		Switch
006	A141403		Not Available	TRANSFORMER (24 VAC) (FOR MICROPROCESSOR MODELS)
007	A136008	136008		Fuse Block
008	A136057	W10146739		0.5 A 250
009	A150301	150301		8-18 X 7
010	A150002	150002		6-32 X 1
011	A120715	W10146700		30 Pos Ter
012	A151000	WH12X195		Switch Assembly

