


# Maytag MDG30MC3AW 03 - CONTROL BOX ASSEMBLY



Maytag Residential Maytag MDG30MC3AW Dryer Parts Parts Diagram 03 - CONTROL BOX ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A122603	<a href="#">122603</a>		9 Pin Sock
002	A122701	<a href="#">122701</a>		MNL Socket
"	A122801	<a href="#">W10146716</a>		Mate-N-Loc
003	A315010	<a href="#">315010</a>		Door Outer Half White
004	A150300	<a href="#">5307527001</a>		Switch
005	A150300	<a href="#">5307527001</a>		Switch
006	A141403		Not Available	TRANSFORMER (24 VAC) (FOR MICROPROCESSOR MODELS)
007	A136008	<a href="#">136008</a>		Fuse Block
008	A136057	<a href="#">W10146739</a>		0.5 A 250
009	A150301	<a href="#">150301</a>		8-18 X 7
010	A150002	<a href="#">150002</a>		6-32 X 1
011	A120715	<a href="#">W10146700</a>		30 Pos Ter
012	A151000	<a href="#">WH12X195</a>		Switch Assembly

