


Maytag MDG30PC2AL 11 - MAIN DOOR SWITCH HOUSING (PC2)



Maytag [Residential Maytag MDG30PC2AL Dryer Parts](#) Parts Diagram 11 - MAIN DOOR SWITCH HOUSING (PC2)
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|---------------------------|---------------|--|
| 000 | W10124350 | | Not Available | ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000 |
| 001 | A152013 | 152013 | | 6-32 Hex N |
| 002 | A153008 | 153008 | | 6 Split L |
| 003 | A137005 | W10146741 | | SDS Door S |
| 004 | A121028 | 121028 | | 1 4 X.032 |
| 005 | A154281 | 154281 | | 3 8 Stand |
| 006 | A800448 | 800448 | | 12 1 2 Ma |
| 007 | A153565 | 153565 | | 6-32 X 1 S |
| 008 | A313218 | | | MAIN DOOR |
| 009 | A150201 | 150201 | | 10-32 X 1 |
| 010 | A121405 | 121405 | | Rubber Gro |