



Maytag [Residential Maytag MDG30PC2AW Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL ASSEMBLY (PC2)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A112526	W10146647		Phase 5 CO
002	A801213		Not Available	PANEL, CONTROL (COMPLETE) (INCL. KEYBOARD/CONTROLLER)
"	A801229		Not Available	PANEL, CONTROL (COMPLETE) (KEYBOARD/CONTROL/BATT. BRKT)
"	A801258		Not Available	PANEL, CONTROL (W/BATT. BRKT) (W/BATTERY BRACKET)
"	A801259		Not Available	PANEL, CONTROL (ONLY)
003	A150309	W10146761		10-16 X 1
004	A136048	136048		0.125A 2
"	A137213	W10146476		Phase 5 CO
"	A824998	824998		Phase-5 BA
005	A153010	153010		6 Internal

006	A150005		6-32 X 1 4
007	A125100	W10148718	25C US Acc
"	A125767		Coin Acceptor
008	A137056	W10146742	Optical SW
"	A880772	W10148033	24V Single
009	A137023	137023	3P Mrii Fe
010	A137021	137021	Mr Recept 2
011	A122800		M R EXTRAC

