


Maytag MDG30PC3AW 01 - CONTROL PANEL ASSEMBLY (PC3)



Maytag [Residential Maytag MDG30PC3AW Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL ASSEMBLY (PC3)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A112526	W10146647		Phase 5 CO
"	A801213		Not Available	PANEL, CONTROL (COMPLETE) (INCL. KEYBOARD/CONTROLLER)
"	A801229		Not Available	PANEL, CONTROL (COMPLETE) (KEYBOARD/CONTROL/BATT. BRKT)
002	A801258		Not Available	PANEL, CONTROL (W/BATT. BRKT) (W/BATTERY BRACKET)
"	A801259		Not Available	PANEL, CONTROL (ONLY)
003	A150309	W10146761		10-16 X 1
004	A137213	W10146476		Phase 5 CO
"	A824998	824998		Phase-5 BA
005	A153010	153010		6 Internal
006	A150005			6-32 X 1 4

007	A125100	W10148718	25C US Acc
008	A137056	W10146742	Optical SW
009	A137023	137023	3P Mrii Fe
010	A137021	137021	Mr Recpt 2
"	A880772	W10148033	24V Single
011	A136048	136048	0.125A 2
012	A122800		M R EXTRAC
013	W10124350	Not Available	IMPORTANT: CHECK LABEL ON COMPUTER CHIP TO VERIFY

