


# Maytag MDG32PC3AL 19 - BURNER BOX/PIPING ASSEMBLIES



Maytag Residential Maytag MDG32PC3AL Dryer Parts Parts Diagram 19 - BURNER BOX/PIPING ASSEMBLIES  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS AT AMERICAN DRYER CORP AT 508-678-9000
001	A150301	<a href="#">150301</a>		8-18 X 7
002	A880121	<a href="#">W10147954</a>		430 Burner
003	A150301	<a href="#">150301</a>		8-18 X 7
004	A318702	<a href="#">318702</a>		230 530 To
005	A150300	<a href="#">5307527001</a>		Switch
006	A141305		Not Available	BODY, UNION SHUT-OFF
007	A142823	<a href="#">142823</a>		1 2 X 40 B
008	A150300	<a href="#">5307527001</a>		Switch
009	A318700	<a href="#">W10146865</a>		SM Burner
010	A142600	<a href="#">142600</a>		1 2 Black
011	A141237	<a href="#">141237</a>		430 Inlet
012	A150301	<a href="#">150301</a>		8-18 X 7
013	A880121	<a href="#">W10147954</a>		430 Burner
014	A150301	<a href="#">150301</a>		8-18 X 7

015	A142600	<a href="#">142600</a>	1 2 Black
016	A150300	<a href="#">5307527001</a>	Switch
017	A318700	<a href="#">W10146865</a>	SM Burner
018	A142823	<a href="#">142823</a>	1 2 X 40 B
019	A141305	Not Available	BODY, UNION SHUT-OFF
020	A130401		HI-LIMIT (ONLY) (330 DEG.)
021	A150300	<a href="#">5307527001</a>	Switch
022	A318065	<a href="#">318065</a>	320 330 43
023	A150300	<a href="#">5307527001</a>	Switch
024	A850912	<a href="#">850912</a>	320 330 43

