


Maytag MDG32PC3AW 08 - DOOR SWITCH ASSEMBLY



Maytag Residential Maytag MDG32PC3AW Dryer Parts Parts Diagram 08 - DOOR SWITCH ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A152013	152013		6-32 Hex N
002	A153010	153010		6 Internal
003	A137005	W10146741		SDS Door S
004	A154281	154281		3 8 Stand
005	A800448	800448		12 1 2 Ma
006	A313248		Not Available	HOUSING, MAIN DOOR SWITCH
007	A150201	150201		10-32 X 1
008	A121405	121405		Rubber Gro