


# Maytag MDG3600BWQ 03 - DOOR



Maytag Residential Maytag MDG3600BWQ Dryer Parts Parts Diagram 03 - DOOR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">33001767</a>			Seal, Shroud
2	<a href="#">33002597</a>			Hook, Security
3	33002436		Not Available	SHROUD, (BSQ)
4	<a href="#">22001995</a>			Screw Note: Screw, Tumbler Front And Shroud
5	<a href="#">22002239</a>			Clip, Front Panel
"	<a href="#">33002368</a>			Panel, Front
"	213280	<a href="#">204439</a>		Screw And Fstner Assembly
6	33001508	<a href="#">W10169313</a>		Switch-Dor
7	<a href="#">33001760</a>			Bracket, Hinge
8	<a href="#">33001763</a>			Plug, Inner Door
9	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
"	33001791	<a href="#">306436</a>		Door Latch Kit--W
10	<a href="#">33002094</a>			Seal, Door
11	33001268		Not Available	PAD, DOOR
12	<a href="#">22002038</a>			Clip, Door
13	<a href="#">33002349</a>			Cover, Hinge Hole

"	<a href="#">22002244</a>		Clip, Grounding
14	<a href="#">33001793</a>		Bracket, Strike
15	<a href="#">33001761</a>		Strike, Door
16	<a href="#">22002243</a>		Screw, Front Panel And Hinge
17	<a href="#">33001763</a>		Plug, Inner Door
18	<a href="#">33002351</a>		Screw
"	33002439	Not Available	DOOR, INNER (BSQ)
19	<a href="#">33002371</a>		Door, Outer
20	<a href="#">33001759</a>		Hinge, Door
21	22002062	<a href="#">98006631</a>	Screw
22	<a href="#">33002351</a>		Screw
23	22002062	<a href="#">98006631</a>	Screw

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>