


Maytag MDG3600BWW 02 - CONTROL PANEL



Maytag [Residential Maytag MDG3600BWW Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y22002339	8534058		Screw
"	33002721			Facia, Control Panel
2	22003951			Dial Skirt
3	22003915			Timer Knob
4	22001664			Timer Knob Insert/Cap
5	33001619	37001071		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33002689			Timer, Mallory Electronic Dry
8	22002529		Not Available	CONSOLE BACK PANEL
"	22002925	3370225		Screw
9	33002286		Not Available	CONSOLE (WHT)
10	22002925	3370225		Screw
11	33001623			Buzzer, Non-Adjustable
13	33002389			Dryness Display Control Note: Display, Dryness
14	33001641			Switch, Temperature

