



[Maytag Residential Maytag MDG3757AWW Dryer Parts Parts Diagram 04 - SUPPLEMENTAL INFORMATION](#)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">37001153</a>			Harness, Wire
"	<a href="#">61923</a>			Block, Terminal
"	Y61199	<a href="#">3400094</a>		Screw, 10-32 X 3/8
2	33002053	<a href="#">211881</a>		Grommet, Cord Part Not Used- Gas Models Only
3	2206673		Not Available	MANUAL, USE & CARE DRYER
"	Y2205339		Not Available	MANUAL, USE & CARE
4	<a href="#">21001980</a>			Lead Assembly
5	<a href="#">37001147</a>			Soundfoil
6	<a href="#">37001113</a>			Sound Foam
7	33002494	<a href="#">33002778</a>		Power Cord
8	16026315		Not Available	SVC MAN, DOM DRYER GAS
9	Y504105	<a href="#">Y504105A</a>		Rack-Dry
10	649P3	<a href="#">LPK1</a>		LP Gas Con
11	<a href="#">650P3</a>			Kit, Gas Burner Conversion
12	<a href="#">528P3</a>			Directional Exhaust Kit

