


Maytag MDG6000AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG6000AWW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002328	33002697		Control Panel, Facia / White
"	Y22002339	8534058		Screw
2	33001621			Skirt, Timer Dial
3	22001659			Timer Knob - Grey
"	22001659			Timer Knob - Grey
"	22001664			Timer Knob Insert/Cap
"	33001621			Skirt, Timer Dial
4	22001664			Timer Knob Insert/Cap
5	33001619	37001071		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33001932			Timer
8	216423	3370225		Screw
"	22002529		Not Available	CONSOLE BACK PANEL
9	33002286		Not Available	CONSOLE (WHT)
10	33001861	33001618		Switch- PU
11	33001936			Wire Harness, Main

12	33001653		Switch, Temp 4 Pos
13	22001788		Button, Switch
14	22001789		Button, Switch
15	33002389		Dryness Display Control Note: Display, Dryness
16	33002554	Not Available	MANUAL, USE & CARE (FRCH)
"	33002391		Manual, Use And Care

