


# Maytag MDG6460AWW 02 - CONTROL PANEL



Maytag Residential Maytag MDG6460AWW Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002726		Not Available	FACIA, CONTROL PANEL
2	22003953	<a href="#">22004165</a>		Timer Dial Skirt
3	<a href="#">22003993</a>			Timer Knob
4	<a href="#">22003989</a>			Timer Cap White
5	<a href="#">22003987</a>			Control Knob White
6	<a href="#">22002733</a>			Washer Fill Hose, 4'
7	<a href="#">33002803</a>			Timer
8	<a href="#">33002738</a>			Dryer Switch Support
9	22003960		Not Available	CONSOLE HOUSING (WHT)
10	<a href="#">33002725</a>			4 Pos. Rotary Temp. Switch
11	<a href="#">33002750</a>			Buzzer Switch
12	22003938	<a href="#">8534058</a>		Screw