


Maytag MDG7460AWW 02 - CONTROL PANEL



Maytag Residential Maytag MDG7460AWW Dryer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002830	33002728		Facia, Control Panel
2	22003953	22004165		Timer Dial Skirt
3	22003993			Timer Knob
4	22003989			Timer Cap White
5	22003987			Control Knob White
6	33001855	33002917		Screw, No.10-16
7	33002803			Timer
"	33002748	33002855		Timer
8	33002738			Dryer Switch Support
9	22003960		Not Available	CONSOLE HOUSING (WHT)
10	33002725			4 Pos. Rotary Temp. Switch
11	33002736			On.off Switch
12	22003938	8534058		Screw
13	33002905			Sensor Assembly
"	33002734			3 Light Dryness Display
14	33002746			Lens Carrier Assembly

