


# Maytag MDG8400AWQ 02 - CONTROL PANEL



Maytag [Residential Maytag MDG8400AWQ Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002731		Not Available	FACIA, CONTROL PANEL (BSQ)
"	22003938	<a href="#">8534058</a>		Screw
2	22003954		Not Available	TIMER DIAL SKIRT (BSQ)
3	<a href="#">22003952</a>			Knob, Timer
4	<a href="#">22003990</a>			Timer Cap
5	22003988	<a href="#">22003987</a>		Control Knob White
"	22004050		Not Available	ENG. TOL. COMPENSATOR (SPACER)
6	33001855	<a href="#">33002917</a>		Screw, No.10-16
7	33002732		Not Available	CHIME / BUZZER
"	<a href="#">33002743</a>			4 Position Chime Switch
"	<a href="#">33002808</a>			Timer
"	<a href="#">33002854</a>			Timer
"	<a href="#">33002855</a>			Timer
"	<a href="#">33002871</a>			Switch, 4 Position
8	<a href="#">33002738</a>			Dryer Switch Support

9	<a href="#">22003975</a>		Console Housing
10	<a href="#">33002724</a>		Rotary Infinite Temp. Switch
11	<a href="#">22003978</a>		Switch, Rocker
12	22003938	<a href="#">8534058</a>	Screw
13	<a href="#">33002734</a>		3 Light Dryness Display
"	<a href="#">33002905</a>		Sensor Assembly
"	33001855	<a href="#">33002917</a>	Screw, No.10-16
14	<a href="#">33002747</a>		Lens Carrier Assembly

