


# Maytag MDG8416AWA 03 - CONTROL PANEL



Maytag [Residential Maytag MDG8416AWA Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y22002339	<a href="#">8534058</a>		Screw
"	33001914		Not Available	PANEL, CONTROL (ALM)
2	33001622	<a href="#">33002346</a>		Skirt, Timer Dial
3	<a href="#">22001659</a>			Timer Knob - Grey
4	<a href="#">22001665</a>			Insert, Timer Knob
5	33001620	<a href="#">33002435</a>		Button, Push-To-Start
6	33001690	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	<a href="#">33001632</a>			Timer
8	210186	<a href="#">3370225</a>		Screw
9	33001859		Not Available	WIRE, GROUND
10	216423	<a href="#">3370225</a>		Screw
11	<a href="#">33001623</a>			Buzzer, Non-Adjustable
12	33001862	<a href="#">33001618</a>		Switch- PU
13	<a href="#">33001912</a>			Wire Harness, Main
14	<a href="#">33001643</a>			Switch, Temperature
15	22001667	<a href="#">22002589</a>		Knob, Selector

16	33001806	Not Available	BACK, CONSOLE PANEL
"	216423	<a href="#">3370225</a>	Screw
17	22002286	<a href="#">22004094</a>	Facia, Export Mav7750
18	33001902	Not Available	MANUAL, USE & CARE

