


# Maytag MDG8426AGW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG8426AGW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33001942		Not Available	PANEL, CONTROL (WHT)
"	Y22002339	<a href="#">8534058</a>		Screw
2	<a href="#">33001621</a>			Skirt, Timer Dial
3	<a href="#">22001659</a>			Timer Knob - Grey
4	<a href="#">22001664</a>			Timer Knob Insert/Cap
5	33001619	<a href="#">37001071</a>		Button, Push-To-Start
6	33001690	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	<a href="#">33001636</a>			Timer
8	912365	<a href="#">3370225</a>		Screw
9	33001859		Not Available	WIRE, GROUND
10	216423	<a href="#">3370225</a>		Screw
11	<a href="#">33002252</a>			Buzzer
12	33002251	<a href="#">33001618</a>		Switch- PU
13	<a href="#">33001944</a>			Wire Harness, Main
14	<a href="#">33001638</a>			Switch, Temperature
15	<a href="#">22001942</a>			Washer, Sealing

"	<a href="#">22001663</a>		Knob, Selector Switch
16	33001806	Not Available	BACK, CONSOLE PANEL
"	216423	<a href="#">3370225</a>	Screw
17	22002285	Not Available	CONSOLE (WHT)
18	33001902	Not Available	MANUAL, USE & CARE

