


Maytag MDG9306AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG9306AWW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33001924			Panel, Control
"	Y22002339	8534058		Screw
2	33001621			Skirt, Timer Dial
3	22001659			Timer Knob - Grey
4	22001664			Timer Knob Insert/Cap
5	33001619	37001071		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33001631			Timer
8	210186	3370225		Screw
9	33001859		Not Available	WIRE, GROUND
10	216423	3370225		Screw
11	33001623			Buzzer, Non-Adjustable
12	33001861	33001618		Switch- PU
13	33001927			Wire Harness, Main
14	33001639			Switch, Temperature
15	22001663			Knob, Selector Switch

16	33001806	Not Available	BACK, CONSOLE PANEL
"	216423	3370225	Screw
17	22002285	Not Available	CONSOLE (WHT)

