


**Maytag MDG9316AWQ 03 - CONTROL PANEL
(MDE/MDG9316AWQ/AYQ/AXW)**



Maytag [Residential Maytag MDG9316AWQ Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
(MDE/MDG9316AWQ/AYQ/AXW)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33002352			Panel, Control
"	Y22002339	8534058		Screw
2	33002346			Skirt, Timer Dial
3	22001659			Timer Knob - Grey
4	33002347			Timer Knob Insert/Cap
5	33002324	33002435		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33001631			Timer
8	210186	3370225		Screw
9	33001859		Not Available	WIRE, GROUND
10	216423	3370225		Screw
11	33001623			Buzzer, Non-Adjustable
12	33002356	33001618		Switch- PU
13	33001929			Wire Harness, Main

14	33001639		Switch, Temperature
15	22002589		Knob, Selector
16	216423	3370225	Screw
"	33001806		Not Available
			BACK, CONSOLE PANEL
17	33002327	37001115	Console
18	33001902		Not Available
			MANUAL, USE & CARE
"	33001911		Not Available
			MANUAL, USE & CARE (FRENCH)

