


Maytag MDG9806AWW 03 - CONTROL PANEL



Maytag [Residential Maytag MDG9806AWW Dryer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y22002339	8534058		Screw
"	33001937			Panel, Control
2	33001621			Skirt, Timer Dial
3	22001659			Timer Knob - Grey
4	22001664			Timer Knob Insert/Cap
5	33001619	37001071		Button, Push-To-Start
6	33001690	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	33001730			Timer
8	210186	3370225		Screw
9	33001859		Not Available	WIRE, GROUND
10	33001860	W10116760		Screw
11	33001848			Signal, End Of Cycle
12	33001861	33001618		Switch- PU
13	33001887		Not Available	WIRE HARNESS, MAIN
14	22001906	22001908		Switch, Option
15	22001788			Button, Switch

16	22001789		Button, Switch
17	33001661	33002389	Dryness Display Control Note: Display, Dryness
18	33001657		Switch, Temperature
19	33001806	Not Available	BACK, CONSOLE PANEL
"	216423	3370225	Screw
20	22002285	Not Available	CONSOLE (WHT)

