


Maytag MED5840TW1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MED5840TW1
(White)

29" ELECTRIC DRYER



10-07 LITHO IN U.S.A. (LAN)

1

Part No. W10169178 Rev. A

Maytag [Residential Maytag MED5840TW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089171		Not Available	Sheet, Cycle Feature
"	W10088770		Not Available	Guide, Use & Care
"	8576803		Not Available	Wiring Diagram
2	W10113080			Wire, Jumper
3	359625	487240		Screw, For Mtg. Service Capacitor
4	3405154			Switch Rotary
5	W10112578			Harness, Bracket
6	W10117655			Switch, Push-To-Start
7	694419			Mini-Buzzer
8	343641	681414		Screw, 10AB X 1/2
9	8578352			Switch, Temperature
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	8312709			Clip-Console
13	688983	487240		Screw, For Mtg. Service Capacitor

14	237446	487596	Washer
15	3395683		Receptacle, Multi-Terminal
16	W10112599		Top
17	W10110035		Knob
18	3394427		Clip-Harness
19	337686	Not Available	SCREW, 8-18 X .500
20	3401144		Connector
21	3406725		Timer Assembly
22	8558178		Control, Electronic
23	W10112603		Seal, Harness
24	3391885		Connector, Edge
25	W10110036		Knob
26	W10086716	W10142694	Console
27	W10112569	W10203949	Medallion
29	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
30	3936144		Do-It-Yourself Repair Manuals
31	W10110994		Harness, Wiring
32	3397269		Connector, Timer
33	3347243		Block, Disconnect
34	94614		Terminal
35	W10112577		Panel, Rear Console

