


Maytag MED5870TW1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MED5870TW1
(White)

29" ELECTRIC DRYER



9-07 Litho in U.S.A. (LT)

1

Part No. W10167265 Rev. A

Maytag Residential Maytag MED5870TW1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089171		Not Available	Sheet, Cycle Feature
"	W10088770		Not Available	Guide, Use & Care
"	8578889		Not Available	Wiring Diagram
2	W10112577			Panel, Rear Console
3	693995			Screw, Hex Head
4	W10113080			Wire, Jumper
5	8566184			Timer Assembly
6	3405156			Switch, Rotary
7	694419			Mini-Buzzer
8	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	8578352			Switch, Temperature
10	W10117655			Switch, Push-To-Start
11	W10086717	W10142695		Console
12	8312709			Clip-Console
13	W10112569	W10203949		Medallion
14	8536939			Clip, Knob

15	W10110035		Knob
16	W10110036		Knob
17	337686	Not Available	SCREW, 8-18 X .500
18	W10112578		Harness, Bracket
19	W10112603		Seal, Harness
20	3936144		Do-It-Yourself Repair Manuals
21	237446	487596	Washer
22	3391885		Connector, Edge
23	8558178		Control, Electronic
24	343641	681414	Screw, 10AB X 1/2
25	W10110993		Harness, Wiring
26	8565972		Screen, Lint
27	688983	487240	Screw, For Mtg. Service Capacitor
28	W10112599		Top
29	3395683		Receptacle, Multi-Terminal
30	3394427		Clip-Harness
31	3401144		Connector
32	3397269		Connector, Timer
33	3347243		Block, Disconnect
34	94614		Terminal

