


Maytag MEDB850YG0 02 - CABINET PARTS



CABINET PARTS
For Models: MEDB850YW0, MEDB850YG0
(White) (Granite)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10421629

3

Maytag [Residential Maytag MEDB850YG0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|-------------|--------|--|
| 1 | W10007520 | | | Clip, Ground |
| 2 | 3390631 | | | Screw, 10-16 X 3/8 |
| 3 | 693995 | | | Screw, Hex Head |
| 4 | 3397659 | | | Block, Terminal |
| 5 | W10314253 | | | Switch, Assembly Broken Belt |
| 7 | W10223154 | | | Cabinet |
| " | W10338830 | | | Cabinet |
| 8 | W10363894 | | | Foot, Dryer |
| NI | 279810 | | | Foot-Optional |
| 9 | 660658 | | | Clamp, Motor Mounting 343481 685441 |
| 10 | 3387374 | | | Spring, Idler |
| 11 | 3389420 | | | Retainer-Idler 1/4-20 X 1/16 |
| 13 | 8547160 | | | Pulley Assembly |
| 14 | 279318 | | | Terminal Tinned And Brass Panel |
| 15 | 8578560 | | | Hole, Plug |

| | | | |
|----|---------------------------|---------------------------|------------------------------|
| 17 | W10323735 | | Badge |
| 18 | W10304170 | | Bezel, Door Clip |
| 19 | 3394083 | | Clip, Front Panel |
| 21 | W10252472 | | Hinge Assembly |
| " | W10304174 | | Assembly, Hinge |
| 22 | W10111888 | | Plug, Strike |
| 24 | W10111905 | | Assembly, Door Catch |
| 25 | W10221653 | W10239307 | Seal-Door |
| 26 | 3393657 | | Restrainer, Belt |
| 27 | W10136932 | | Motor, Assembly 60 Hz |
| 28 | W10140148 | | Panel, Rear |
| 29 | W10139247 | | Pulley, Blower |
| 30 | W10136934 | | Belt, Drive |
| 31 | W10136930 | | Pulley, |
| 32 | W10308685 | | Bracket, Motor |
| 33 | 279393 | | Terminal Block Screw Kit |
| 34 | 3389420 | | Retainer-Idler 1/4-20 X 1/16 |
| 35 | 8568303 | | Locator, Snap Down |
| 36 | 3393008 | 308685 | Side Trim) |
| 37 | W10111906 | W10295405 | Strike |
| 38 | W10144494 | | Plug-Hole |
| 39 | W10223442 | W10312757 | Panel |
| " | W10252456 | | Front Panel |
| 40 | 342055 | 488627 | Screw |
| 41 | W10201785 | | Door Switch Assembly |
| 42 | W10252478 | | Door, Outer |
| " | W10344649 | | Door, Outer |
| 43 | 8576625 | | Lock, Front Top |
| 44 | W10044490 | | Seal, Front Panel |
| 45 | W10110241 | | Cover, Terminal Block |
| 46 | 238088 | 8066217 | Hinge, Top |
| 47 | W10111878 | | Door, Inner |
| " | W10304172 | | Door, Inner |
| 48 | w10394552 | | Window-Outer |
| 49 | W10111857 | | Glass, Inner Door |
| 50 | W10111859 | | Gasket, Inner Door |
| 51 | W10316529 | | Foam-Seal Cabinet |
| 52 | W10215725 | | Cover, Door Switch |
| 53 | 8533974 | 4331106 | Screw, No.10-32 X 7/16 |
| 54 | 3400805 | | Screw, 8-18 X 3/64 |
| 55 | W10224768 | | Seal, Foam Spill Guard |