


# Maytag MEDB850YG1 02 - CABINET PARTS



Maytag [Residential Maytag MEDB850YG1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">98234</a>			Clip, U-Bend
2	<a href="#">3390631</a>			Screw, 10-16 X 3/8
3	<a href="#">693995</a>			Screw, Hex Head
4	<a href="#">3397659</a>			Block, Terminal
5	<a href="#">W10314253</a>			Switch, Assembly Broken Belt
7	W10183827	<a href="#">W10223154</a>		Cabinet
"	W10304162		Not Available	CABINET (INCLUDES ITEM 51) (COSMETALLIC)
8	<a href="#">W10363894</a>			Foot, Dryer
NI	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
13	<a href="#">8547160</a>			Pulley Assembly
14	<a href="#">279318</a>			Terminal Tinned And Brass Panel

15	<a href="#">W10363887</a>		Riser-Full
17	<a href="#">W10323735</a>		Badge
18	<a href="#">W10304170</a>		Bezel, Door Clip
19	<a href="#">3394083</a>		Clip, Front Panel
21	<a href="#">W10249708</a>		Hinge, Assembly
"	<a href="#">W10463337</a>		Assembly, Hinge
22	<a href="#">W10111888</a>		Plug, Strike
24	<a href="#">W10111905</a>		Assembly, Door Catch
25	W10221653	<a href="#">W10239307</a>	Seal-Door
26	<a href="#">3393657</a>		Restrainer, Belt
27	<a href="#">W10460374</a>		Motor, Assembly 60 Hz
28	<a href="#">W10140148</a>		Panel, Rear
29	<a href="#">W10139247</a>		Pulley, Blower
30	<a href="#">W10136934</a>		Belt, Drive
31	<a href="#">W10136930</a>		Pulley,
32	<a href="#">8547158</a>		Bracket, Motor
33	<a href="#">279393</a>		Terminal Block Screw Kit
34	<a href="#">3389420</a>		Retainer-Idler 1/4-20 X 1/16
35	<a href="#">8568303</a>		Locator, Snap Down
36	3393008	<a href="#">308685</a>	Side Trim )
37	W10111906	<a href="#">W10295405</a>	Strike
38	<a href="#">W10144494</a>		Plug-Hole
39	<a href="#">W10463261</a>		Front Panel
"	<a href="#">W10463263</a>		Front Panel Z
40	342055	<a href="#">488627</a>	Screw
41	<a href="#">W10350909</a>		Door Switch Assembly
42	<a href="#">W10252478</a>		Door, Outer
"	<a href="#">W10344649</a>		Door, Outer
43	<a href="#">8576625</a>		Lock, Front Top
44	<a href="#">W10044490</a>		Seal, Front Panel
45	<a href="#">W10110241</a>		Cover, Terminal Block
46	238088	<a href="#">8066217</a>	Hinge, Top
47	<a href="#">W10111878</a>		Door, Inner
"	<a href="#">W10304172</a>		Door, Inner
48	<a href="#">w10394552</a>		Window-Outer
49	<a href="#">W10111857</a>		Glass, Inner Door
50	<a href="#">W10111859</a>		Gasket, Inner Door
51	<a href="#">W10316529</a>		Foam-Seal Cabinet
52	<a href="#">W10215725</a>		Cover, Door Switch
53	8533974	<a href="#">4331106</a>	Screw, No.10-32 X 7/16
54	<a href="#">3400805</a>		Screw, 8-18 X 3/64