


Maytag MET3800TW0 01 - WASHER/DRYER CONTROL PANEL PARTS



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.
 5-07 Litho in U.S.A. (LT) 1 Part No. W10128966 Rev. B

Maytag Residential Maytag MET3800TW0 Washer/Dryer Parts Parts Diagram 01 - WASHER/DRYER CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10118289		Not Available	Installation Instructions (English)
"	W10117754		Not Available	Use & Care Guide
"	W10117755		Not Available	Sheet, Cycle Feature
"	W10114285		Not Available	Wiring Diagram
"	W10118320		Not Available	Energy Guide
2	3390688			Spacer- Foam Pad
3	8528583			Bracket, Control
4	W10124193			Timer, Washer
6	W10112571			Dial,
7	W10110033			Knob, Timer
8	W10112572	W10110035		Knob
9	8521965			Gasket, Console
10	8558178			Control, Electronic
11	W10112573	W10110036		Knob
12	3400808			Screw. Mounting

13	W10112533	W10339337	Switch-WL
14	W10114118		Switch, Temperature
15	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	W10117655		Switch, Push-To-Start
18	694419		Mini-Buzzer
19	W10113816		Timer, Dryer
20	W10124093		Panel, Control
21	3389453		Bracket, Hinge
22	3389456		End Cap
23	W10128115		Harness - Dryer
"	2154470		Receptacle,
"	3395683		Receptacle, Multi-Terminal
24	3390604		Clamp, Harness
25	3390422	W10134185	Clip, Harness
26	8536939		Clip, Knob
27	3405156		Switch, Rotary
29	3389464		End Cap

