


Maytag MET3800TW0 02 - DRYER FRONT PANEL AND DOOR PARTS

DRYER FRONT PANEL AND DOOR PARTS

For Models: MET3800TW0
(Designer White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10128966

2

Maytag [Residential Maytag MET3800TW0 Washer/Dryer Parts](#) Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3389249			Nut, Inner Door
2	3391902			Switch, Door
3	98234			Clip, U-Bend
4	3392547	279718		Panel
5	3390735			Seal, Door
6	3392563	280083		Door-Rear
7	3387872			Door, Front
8	3388229			Retainer, Toe Panel
9	3387242			Seal, Front Panel
11	696144	279570		Latch
12	697773	3395530		Screw
13	3393008	308685		Side Trim)
14	3392538	279570		Latch
15	W10116360			Handle, Door
16	3390902			Clip, Door Hinge
17	3388958			Panel, Toe

18

342055

[488627](#)

Screw

19

[3389247](#)

Hinge And Pin Assembly

20

[694091](#)

Trim, Side Right Hand

