


Maytag MET3800TW1 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

DRYER SUPPORT AND WASHER HARNESS PARTS

For Models: MET3800TW1
(Designer White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10143040

7

Maytag [Residential Maytag MET3800TW1 Washer/Dryer Parts](#) Parts Diagram 05 - DRYER SUPPORT AND WASHER HARNESS PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10139637			Harness - Washer
"	3350130			Plug, Terminal
"	3347243			Block, Disconnect
"	352089			Timer, Block Disconnect
"	3350211		Not Available	Receptacle, 3 Way
"	62505			Block, Disconnect
2	3388851			Channel Assembly
3	3388850			Channel Assembly
4	3390609			Shield, Harness
5	8545438			Hose, Pressure Switch
6	2219077			Clip, Pressure Switch Hose
7	343641	681414		Screw, 10AB X 1/2
8	685463			Kit, Grounding Plug, Dryer Side Panel
9	8533071	90767		Screw, 8A X 3/8 HeX Washer

9	6533971	30707	Head Tapping
10	685449		Wire, Ground
11	3401144		Connector
12	22965		Strap, Grounding
13	3400300	Y015627	Screw- Hex
14	3393930	4342911	Nut
15	3394350		Shield, Front
16	3390336		Shield, Thermostat
17	3393008	308685	Side Trim)
18	3391249		Cable Tie, Push Mount
19	3354925		Block, Connector
20	3360056		Connector
21	94613	596797	Terminal
"	94614		Terminal
22	63523		Harness, Protector

