


Maytag MFR18MCAAS 15 - CONTROL PANEL-MC (SERIES 11)



Maytag Residential Maytag MFR18MCAAS Washer Parts Parts Diagram 15 - CONTROL PANEL-MC (SERIES 11)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23003287			Panel, Control
002	NLA		Not Available	PANEL, FACIA (20C ON 3)
003	23002325			Washer
004	NLA		Not Available	PLATE, INDEX (PUSH BUTTONS)
005	NLA		Not Available	PLATE, INDEX
006	23002522			Plate, Index
"	NLA		Not Available	PLATE, INDEX (COIN METER)
007	23002491			Switch, Program Selector
008	23002492			Switch, Func Sel W/Red Button
009	23002493			Switch, Function Selector
010	23002495			Disk, Indicator
"	23002497			Disk, Indicator
011	23001044	23002496		Disk- Indi
012	23001046			Lamp, Indicator

013	23001047	23002525	Plexi Tra
"	23001049		Not Available
"	NLA		Not Available
014	23001670		Washer
015	23001063		Meter, Coin
"	23001350		Meter, Coin
016	23002864		Plate, Fixation
017	23001064		Screw, Ornamental
018	NLA		Not Available
019	23002500		Washer, Lock
020	NLA		Not Available
021	23002399	23001014	Nut M4
022	23001056		Ring, Shaft Locking
023	23001057	23002499	Spring Retaining Clip
024	23001058		Tube, Distance
025	23002111	23001013	Lock Washer External Teeth M4

