


Maytag MFR18MCAAS 23 - CABINET (SERIES 11)



Maytag [Residential Maytag MFR18MCAAS Washer Parts](#) Parts Diagram 23 - CABINET (SERIES 11)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	23003287			Panel, Control
002	NLA		Not Available	BOX/ELECTRICAL COMPONENTS
003	NLA		Not Available	HOLDER, ELEC. COMPONENT BOX
004	23002462			Screw Lu
005	23001335	23002861		Screw Lu
006	23003291			Panel, Side
007	23003293			Panel, Side
008	23003295	23001434		Panel, Rear
009	23003297	23001436		Panel, Access
010	23003298			Support, Side Panel
011	23002354	23002461		Screw
012	NLA		Not Available	PANEL, FRONT
013	NLA		Not Available	HOLDER, COMPONENTS
014	23001442			Cover, Hook
015	23001088	23002473		Rubber, Protective

016	23002463		Screw
017	23001445		Top Clip Spring
018	23001446		Screw
019	23001204		Washer, Finishing
020	23001447		Washer, Fiber
021	23002860		Tube, Distance
022	23001448		Nut, Rapid
023	23001309		Washer Lu
024	23002471	23001310	Nut, Self Locking
025	NLA	Not Available	BOLT (M6X16)
026	23002651	23001312	Mut M6
027	23001734	23002425	Locker Washer M6
028	23001027		Washer

the laundry company[®]

the laundry company[®]

the laundry company[®]