


Maytag MFR18PCAVS 13 - CABINET (SERIES 10)



Maytag [Residential Maytag MFR18PCAVS Washer Parts](#) Parts Diagram 13 - CABINET (SERIES 10)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	PLATE, BACK-UP (COIN METER)
002	NLA		Not Available	TRAY, ELECTRICAL COMPONENTS
003	23001511			Box, Holder
004	NLA		Not Available	CONDENSATORS, BOX
005	23001430	23003291		Panel, Side
006	NLA		Not Available	PANEL, SIDE (RT)
007	23001434			Panel, Rear
008	23001436			Panel, Access
009	23001437			Support, Side Panel Lu
010	NLA		Not Available	PANEL, FRONT
011	23001442			Cover, Hook
012	23001444	23002463		Screw
013	23001445			Top Clip Spring
014	23001446			Screw
015	23001204			Washer, Finishing

016	23001447		Washer, Fiber
017	23001331	23002860	Tube, Distance
018	23001448		Nut, Rapid
019	23001309		Washer Lu
020	23001310		Nut, Self Locking
021	23001449		Locking Nut, Self
022	23001034	Not Available	NUT (M6)
023	23001028	23002756	Lockwasher
024	23001027		Washer
025	23001026		Bolt
026	23001088	23002473	Rubber, Protective
027	NLA	Not Available	BEAM, CROSS

