


Maytag MFR18PDAVS 04 - TOP COVER AND SOAP BOX



Maytag Residential Maytag MFR18PDAVS Washer Parts Parts Diagram 04 - TOP COVER AND SOAP BOX
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23003779			Cover W/Two Locks
002	23001003			Rubber Cover, Soap Box
003	23003781			Dispenser Cover Retainer
004	23001005			Rubber Hose, Soap Box
005	23001006			Lock, Top Panel
006	23001007			Washer M21x27x1
007	23001008			Nut, Lock
008	23001009			Hook, Lock
009	23001011			Nut
010	23001012			Screw
011	23002652			Nut
013	23001015			Rubber Seal, Soap Box
014	23001016			External Soap Hopper
015	23001017			Soap Hopper Insert
016	23001018			Syphon Hose
017	23001019			Fabric Softner Insert

018	23001020		Insert Retainer
019	23001021		Prewash Diverter
020	23001022		Mainwash Diverter
021	23001023		Fabric Softner Diverter
022	23003782		Screw 3 Stainless Steel Lu
023	23001025		Clamp, Hose
024	23002461		Screw
025	23003012		Washer Lu
026	23002440		Washer, Spring Lock
027	23002894	23003484	Screw
028	23001030		Hinge, Top Cover
029	23001031		Shaft, Hinge
030	23001032		Spring Clip
031	23001033		Rivets, Blind Lu
032	23002436	Not Available	NUT (M6)
033	23001550		Sticker, Service Warning
034	23003783		Screw 2

