


Maytag MFR25PDATS 11 - DOOR



Maytag [Residential Maytag MFR25PDATS Washer Parts](#) Parts Diagram 11 - DOOR
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|--------------------------|--------|--|
| 001 | 23001363 | | | Ring, Door |
| 003 | 23001364 | | | Glass, Door |
| 004 | 23001365 | | | Rubber, Door Glass |
| 005 | 23001366 | | | Plate, Hinge |
| 006 | 23001166 | | | Shim, Hinge Plate |
| 007 | 23003700 | 12001889 | | Kit, Door Handle Assembly Handle Front And Back Included |
| 008 | 23003633 | | | Lever, Door |
| 009 | 23001168 | | | Door Handle Pivot Pin |
| 010 | 23001169 | | | Spring, Handle Lever |
| 011 | 23002499 | | | Spring Retaining Clip |
| 012 | 23001368 | | | Shim, Hinge Base |
| 013 | 23001369 | | | Pin, Door Lock |
| 014 | 23001172 | | | Shaft, Door Hinge |
| 015 | 23001370 | | | Door Handle Block W/Pin |
| 016 | 23001175 | | | Screw |

| | | | |
|-----|--------------------------|--------------------------|-------------------------------|
| 017 | 23002280 | | Nut M6 |
| 018 | 23002130 | 23001158 | Lockwasher |
| 019 | 23002424 | | Washer M6.4 |
| 021 | 23001373 | | Microswitch, Activating Plate |
| 022 | 23001781 | 23001179 | Screw |
| 023 | 23002111 | 23001013 | Lock Washer External Teeth M4 |
| 024 | 23001181 | | Ring, Retaining |
| 025 | 23002279 | 23002462 | Screw Lu |
| 026 | 23003794 | | Washer |

